





Congratulations on choosing KosherClock<sup>3</sup>, the alarm clock perfect for Shabbat, Yom Tov or all week long! These instructions will help you get your KosherClock<sup>3</sup> set up in no time at all!

**CONTENTS:**

1. QuickStart
2. Installing/Changing the batteries
3. Setting the time and date
4. Setting the alarms
5. Shabbos/Weekday/Travel Modes

Watch our instructional videos:  
[www.Kosher-Innovations.com](http://www.Kosher-Innovations.com)  
(go to the KosherClock<sup>3</sup> page)

**QUICKSTART**


Button	A Quick Tap	Hold for 5 Seconds
 CLOCK	Go to next screen/setting Accept setting	Set time/alarm
 UP	Advance time/date by 1 unit Switch between 12 hour and 24 hour mode (when not in Set mode)	Quick advance
 DOWN	Reverse time/date by 1 unit -On any alarm screen: Disables/enables alarm. -When in Main Time: switch between Hebrew and English Days of the Week	Quick reverse
 VOLUME	Toggle between: -Low volume -High volume -Mute	N/A
SNOOZE (long button at top)	- Stops the alarm from ringing for another 5 minutes - Activates the back-light (any time you press it)	N/A

**INSTALLING/CHANGING THE BATTERIES**

1. Use 2 AAA Batteries (included with KosherClock<sup>3</sup>)
2. Remove KosherClock<sup>3</sup> from protective case (See "How to Open KosherClock<sup>3</sup>" below)
3. Slide thumb across battery cover in direction shown on bottom of KosherClock<sup>3</sup>
4. Insert batteries with Negative side touching the springs (batteries face opposite directions). Installing batteries incorrectly will cause KosherClock<sup>3</sup> to function incorrectly
5. Close battery cover and wait 15 seconds before pressing buttons (**IMPORTANT!**)

**HOW TO OPEN KOSHERCLOCK<sup>3</sup>**



Place your thumb on the **SMALL TRIANGLE** (as shown here) 







Press your thumb against the **SMALL TRIANGLE** while holding the KosherClock<sup>3</sup> body with your other hand.

















Slide the **INNER CLOCK** out of the **OUTER CASE**.

**SETTING THE TIME AND DATE:**

(Starting from the Main screen showing the "K")















Action	What Happens On Screen
Press and hold the  button for 5 seconds	The "K" disappears and the hour will flash.
Press the  (Up) or  (Down) buttons to adjust the hour as required	The hour flashes. There will be a little "A" for AM or "P" for PM to the left of the hour)
TAP  TO ACCEPT THIS SETTING	

(Note: Hold the  or  buttons for more than 5 seconds to make the numbers change faster)

Press the  or  buttons to adjust minutes	The minutes will now flash.
TAP  TO ACCEPT THIS SETTING	
Press the  or  buttons to adjust the year	The year will now flash. A little "Y" will display to the right of the year.
TAP  TO ACCEPT THIS SETTING	
Press the  or  buttons to adjust the month	The month will now flash. A little "M-D" for Month - Day will display to the right of the day.
TAP  TO ACCEPT THIS SETTING	
Press the  or  buttons to adjust the day	The day of the month will now flash.
TAP  TO ACCEPT THIS SETTING	It will now return to the Main Time Display

**SELECTING & SETTING THE ALARMS**


The KosherClock<sup>3</sup> allows you to select both the time of the alarm and on which day it will ring. Here's how:

Action	What Happens On Screen
Tap  to select which alarm to activate.	Cycles from the main Time Display through all Ten alarms
Press and hold the  button for 5 seconds	 SET appears and the day of the week flashes.
Press the  or  buttons to adjust the day of the week	Day flashes. Cycle from Monday to Sunday or WDA for Week Day Alarm. (See WDA below)
TAP  TO ACCEPT THIS SETTING	
Press the  or  buttons to adjust the Hour	Hour flashes. (Note: look for the "A" for AM or "P" for PM)
TAP  TO ACCEPT THIS SETTING	
Press the  or  buttons to adjust the Minutes	Minutes flash.
TAP  TO ACCEPT THIS SETTING	
Press the  button to select the next Alarm, or tap repeatedly to return to the Main Time Display, showing the "K".	 SET will disappear.

**NOTE:** If you do not push any buttons for more than 1 minute, the KosherClock<sup>3</sup> will return to the Time Display automatically. If you were in the middle of setting the time, it will save your latest changes before returning to the Time Display.

## SHABBOS/WEEKDAY/TRAVEL MODES

What sets the KosherClock<sup>3</sup> apart from other alarm clocks is its adjustable, protective cover. It can be oriented over the Main KosherClock<sup>3</sup> Body in three different positions to provide three separate functions.



Main KosherClock<sup>3</sup> Body—showing LCD and buttons

### Weekday Mode:



**How to do it:**  
Orient the cover so that the side with the two long holes will fit over the LCD side of the KosherClock<sup>3</sup>.

**What it does:**  
all buttons can be pressed and the LCD can be viewed

### Shabbos Mode:



**How to do it:**  
Orient the cover so that the side with one hole fits over the LCD side of the KosherClock<sup>3</sup>

**What it does:**  
displays the time but won't allow buttons to be pushed during Shabbos and Yom Tov This avoids *muktzah*

### Travel Mode:




**How to do it:**  
Slide the cover with no holes over the LCD side of the KosherClock<sup>3</sup>

**What it does:**  
Prevents buttons from being pressed or damaged.

This protects the clock from being reset accidentally. Prevents the LCD screen from being scratched or damaged during travel.

## HOW MANY ALARMS ARE ACTIVE?

Look at the top of the KosherClock<sup>3</sup> display to see which Alarm Bell icons are showing. Those that are showing are active alarms.



## FIVE FOR THE PRICE OF ONE: The Weekday Alarm (WDA)

If you want the alarm to ring at the same time, *every day* from Monday through Friday.

choose the option marked . To access this feature, select an alarm and follow the instructions for setting it. When cycling through the Days of the week, you will find "WDA" after Sunday.

It's great if you have a regular routine where you need to get up for work or davening at the same time during the week. Try setting a different WDA alarm for each person in the room or house.

It's also good if you want an alarm to ring so you'll know it's time to pick up the kids from school/be ready to meet them at the door, etc.

## ALARMS

When Alarm is Ringing:

Alarms ring for 1 minute and shut off by themselves.

To stop a ringing alarm: press Up or Down

To adjust volume: press Volume button

To engage "Snooze" for 5 minutes: press Snooze

To deactivate an alarm, press to go to the desired alarm. Then press the Down button.

A deactivated alarm shows . To reactivate, press the Down button.



**NOTE: All setting of times and alarms must be done prior to Shabbat. You may not touch any buttons on Shabbat.**

To **prevent** pressing buttons on Shabbat, put KosherClock<sup>3</sup> in Shabbos Mode. (Shown at left)



## Kosher Innovations

4515 Chesswood Drive, Unit M  
Toronto, Ontario  
Canada, M3J 2V6  
www.Kosher-Innovations.com  
1-866-661-5483

## SHABBOS TIP: SNOOZE

Since you can't use the Snooze on Shabbos, why not set a few alarms spaced 5 minutes apart?