



Brought to you by: **Kosherimage.com™**
producers of KosherLamp and other great products

Congratulations! You are just moments away from making your Shabbat even more pleasurable than it already is. No more worrying about being late for *minyan* or missing your afternoon *chavrusah*. No need to ask someone to wake you. Just follow the simple instructions and you'll soon be waking up *Shabbos* morning in time for minyan... and the alarms shut off by themselves!

KosherClock Features



1. Display time/alarm.
2. Set five different alarm times
3. Digital recording of a 10 second message.
4. Choose your alarm sound; classic beep for **Shabbat**, or pre-recorded message for **weekdays**.
5. Select 12 or 24 hour format
6. Countdown timer -- Maximum 23 hour 59 minutes
7. Holds a 2.2" X 3.4" photo

Operating your KosherClock

NOTE: All setting of times and alarms must be done prior to Shabbat. You may not touch any buttons on Shabbat. Do not use a pre-recorded sound as an alarm on Shabbat, use the standard "Beep" alarm only.

Modes : By pressing the MODE key, you can cycle through the different modes:

Normal display	(press MODE once and the display advances to) →
Set Alarm 1 time	(press MODE once and the display advances to) →
Set Alarm 2 time	(press MODE once and the display advances to) →
Set Alarm 3 time	(press MODE once and the display advances to) →
Set Alarm 4 time	(press MODE once and the display advances to) →
Set Alarm 5 time	(press MODE once and the display advances to) →
Set Countdown timer	(press MODE once and the display advances back to) → Normal Display

Setting the current time of your KosherClock

From the normal display state, press and hold MODE for 2 seconds until the digits flash to begin setting the current time. Then press HOUR to adjust the hour and press MIN to adjust minutes. By holding down the HOUR or MIN key, the digits will advance rapidly. When the time is correct, press MODE again to confirm the setting. If you do not touch any button for 1 minute, the LCD will stop flashing and automatically confirm the set time.

Setting the Display Time Format (12 hour, or 24 hour)

Press HOUR under normal display state to switch between 12 or 24 hour format.

NOTE: All setting of times and alarms must be done prior to Shabbat. You may not touch any buttons on Shabbat. Do not use a pre-recorded sound as an alarm on Shabbat, use the standard “Beep” alarm only.

Setting the Alarms on your KosherClock

To set Alarm 1, press MODE once from the normal display and your KosherClock will enter “set Alarm 1 time” mode. Then press and hold MODE for 2 seconds until the digits flash, then press HOUR to adjust the hour and press MIN to adjust minutes. By holding down the HOUR or MIN key, the digits will advance rapidly. When the alarm time is correct, press MODE again to confirm the setting. If the alarm is set, the LCD will display the time with a numbered alarm bell like this



To clear the alarm, while in the set alarm MODE, press and hold the MIN key. If alarm has been cleared, the LCD will display as



To set Alarm 2, press MODE two times from normal display, and repeat steps as for Alarm 1.

To set Alarm 3, press MODE three times from normal display, and repeat steps as for Alarm 1.

To set Alarm 4, press MODE four times from normal display, and repeat steps as for Alarm 1.

To set Alarm 5, press MODE five times from normal display, and repeat steps as for Alarm 1.

Setting the Countdown timer on your KosherClock

To set the countdown timer, press MODE six times from normal display state, and your KosherClock will enter “set countdown timer” mode. Repeat steps as for Alarm 1.

If the countdown Alarm is set, the LCD will display like this.



If the countdown timer is cleared, the LCD will display as .



Press MIN to start or pause the countdown alarm.

When the countdown time is expired, the alarm will ring.

(NOTE: DO NOT USE COUNTDOWN TIMER ON SHABBAT)

Setting the Alarm Ringing Options

Slide the switch to BEEP position indicated by the  and when any of the Alarms go off, a “beeping” sound will be heard for 60 seconds and stop. Slide the switch to the MSG position, and when any of the Alarms go off, your pre-recorded message will play for 60 seconds and stop. **Use this feature on weekdays only.** Slide the switch to MUTE position, and even when the alarm is on, the alarm will be mute. This is convenient if you want to keep the same alarms for each Shabbos and not want to hear them during the week. Simply slide your KosherClock to MUTE during the week. Just before the next Shabbos, slide the switch to BEEP, and your Alarms will still be there from the previous week.

Recording your Message

Your KosherClock comes with a pre-recorded melody that you may use as your Alarm on **weekdays**. If you choose, you, or a loved one may record a message via the built-in microphone for **weekday use**. Slide the switch to MSG position. Press and hold down the REC button (with the tip of a ballpoint pen) for recording your 10 second message. Hold down the REC button the whole time you are recording. Press PLAY to play back what you recorded. When the alarm symbol flashes, the recorded message will be played for 60 seconds, used as a wake-up alarm or a reminder. (Do not use recorded alarms on Shabbat).

Maintenance

The clock is designed to be used with two alkaline batteries size AAA. Please replace the batteries when sound is distorted during playback or when display is unclear. Open the battery compartment at the bottom of the KosherClock to replace the battery.